



see. control. automate.



NELA

Distribution Unit

The Trend-Setting Logistic Concept
for Storage and Management of Printing Plates



- * A new, intelligent way of sorting plates *
- * Inline with CtP and punchbending equipment *
- * No more manual sorting *



610 Whitetail Blvd • River Falls, WI • 54022 • USA
Worldwide: 1-715-425-1900
USA/Canada Toll-Free: 1-888-407-4808
FAX: 1-715-425-1901
E-Mail: info@nela-usa.com
Web Site: www.nela-usa.com



NELA

Plate Distribution Unit

OVERVIEW

The NELA Plate Distribution Unit for printing plates presents an efficient way of storing large amount of plates without damage. Its purpose is to store imaged, punched and bent printing plates in the detachable roller carts. Then plates can be transported to the press or to any chosen storage area.




OPERATION

Whenever pages are received from Editorial, they immediately can be imaged, punched and bent. Once out of the punchbender, the plates are scanned via barcode reader and then conveyed to the Distribution Unit. The Unit automatically sorts the press-ready plates in the order that has been chosen by the operator.

All your press operators need to do is detach the cart from the unit and roll them to their destination.

No more sorting by hand, scratched images, damaged bends or costly reruns.




TECHNICAL HIGHLIGHTS:

- For all plate sizes used in newspaper, web or sheetfed offset printing.
- Accepts different plate sizes as well as register punching and bending configurations.
- One (1) Distribution Unit may have one (1) or more cart docking stations.
- Each plate cart holds a minimum of 24 plates dependent upon engineering specified cart heights, room and doorway physical constraints.
- Loading capacity is extendable according to customer's requirements.
- Touch screen interface allows for seamless control.
- Push button diversion of plate remakes to bent plate stacker in front of distribution unit.
- Electronic control of all production steps guarantees trouble-free operation.

- Easy programming of desired plate distribution pattern.

OUR SERVICE—WE ARE HERE FOR YOU !

- 24/7 Service: Our Toll-Free Number allows you easy 24/7 access to us. No multiple phone numbers to remember, just one convenient number.
- Spare Parts available in 24 hours: Full spare parts inventory in Oakdale, MN – ready to be shipped as fast as needed.
- Certified operator and maintenance training at our Minnesota Training Center.
- Remote control, online diagnostic from our Service Department directly to your NELA equipment in the field. Saves time and money.
- Experienced team of NELA Service Engineers constantly trained and ready to install and maintain our equipment in the field.
- Preventative Maintenance program available.



610 Whitetail Blvd • River Falls, WI • 54022 • USA
 Worldwide: 1-715-425-1900
 USA/Canada Toll-Free: 1-888-407-4808
 FAX: 1-715-425-1901
 E-Mail: info@nela-usa.com